

Setting up a bintec hotspot

You will have to match your router configuration with your syces configuration.

Re-Authenticaition with MAC-Address

To Re-Authenticate the User by using the MAC-Adress you need to modify the Walled-Garden URL of the hotspot.

Add the marked Part to the end of the Walled-Garden Address: “<walled-garden-address>/<cid>/<lid>/?mac=\${CLIENT_MAC}”

Standard Setup versus Self Ticketing

Standard Setup

1. You create accounts or vouchers for your hotspot users in advance.
2. They will get to see the default router login page that consists of a left-hand login frame and a second frame that can

be adapted to your needs. Users are asked to enter username and password in the left hand frame.

Self-Ticketing

1. Users may register to create their own accounts.
2. Depending on which option you offer they will get to see the corresponding walled garden page. This may include a login frame, a registration frame, automatic login and reauthentication.

Basic Router Setup for all hotspots

Radius Server

The radius server is configured in **system > remote authentication**. You need two entries:

1. Login Authentication
2. Accounting

Overview corresponding entries router and syces

Syces: Location > Walled Garden Options		Router: Hotspot Gateway	
	Authentication method		
	inactive	Walled Garden	NOT enabled
		advanced settings:	
		Login Frameset	active
	Default Free Service	Walled Garden	enabled
		Walled Network/Netmask	
		advanced settings:	
		Login Frameset	active

From:
<https://help.syces.de/> - SyCes Handbuch

Permanent link:
https://help.syces.de/doku.php/en/syces/hotspot_setup_bintec

Last update: **2020/12/31 07:53**

